

decora smart™

LEVITON®

Leviton Decora Smart™ Switch with HomeKit™ Technology

Cat. No. DH15S

Universal Electronic Switch

Rated: 120/277 VAC, 60 Hz
1800W Incandescent
5A, 600W LED/CFL
15A (120 VAC) Fluorescent
8A (277 VAC) Fluorescent
15A Resistive
1/2 HP Motor

INSTALLATION INSTRUCTIONS

Use Siri® or the Leviton Decora Smart Home app on your iPhone or iPad for home control



© 2017 Leviton Mfg. Co., Inc.

DI-000-DH15S-02A

COPYRIGHT AND TRADEMARK INFORMATION

Decora is a registered trademark of Leviton Manufacturing Co., Inc. Apple, iPhone, iPad, Apple TV and Siri are trademarks of Apple Inc., registered in the U.S. and other countries. HomeKit is a trademark of Apple Inc. Use herein of third party trademarks, service marks, trade names, brand names and/or product names are for informational purposes only, are/may be the trademarks of their respective owners; such use is not meant to imply affiliation, sponsorship, or endorsement. No part of this document may be reproduced, transmitted or transcribed without the express written permission of Leviton Manufacturing Co., Inc.

TECHNICAL SUPPORT

For additional information contact Leviton's Technical Support at: **1-800-824-3005** or visit Leviton's website at www.leviton.com

FOR CANADA ONLY

For warranty information and/or product returns, residents of Canada should contact Leviton in writing at **Leviton Manufacturing of Canada Ltd to the attention of the Quality Assurance Department, 165 Hymus Blvd, Pointe-Claire (Quebec), Canada H9R 1E9** or by telephone at **1-800-405-5320**.

LIMITED 5 YEAR WARRANTY AND EXCLUSIONS

Leviton warrants to the original consumer purchaser and not for the benefit of anyone else that this product at the time of its sale by Leviton is free of defects in materials and workmanship under normal and proper use for five years from the purchase date. Leviton's only obligation is to correct such defects by repair or replacement, at its option. **For details visit www.leviton.com or call 1-800-824-3005.** This warranty excludes and there is disclaimed liability for labor for removal of this product or reinstallation. This warranty is void if this product is installed improperly or in an improper environment, overloaded, misused, opened, abused, or altered in any manner, or is not used under normal operating conditions or not in accordance with any labels or instructions. **There are no other or implied warranties of any kind, including merchantability and fitness for a particular purpose,** but if any implied warranty is required by the applicable jurisdiction, the duration of any such implied warranty, including merchantability and fitness for a particular purpose, is limited to five years. **Leviton is not liable for incidental, indirect, special, or consequential damages, including without limitation, damage to, or loss of use of, any equipment, lost sales or profits or delay or failure to perform this warranty obligation.** The remedies provided herein are the exclusive remedies under this warranty, whether based on contract, tort or otherwise.


© 2017 Leviton Mfg. Co., Inc.

DI-000-DH15S-02A

Step 5 Testing your Switch prior to mounting in wall box:




- Position all wires to provide room in outlet wall box for switch.
 - Ensure that the word "TOP" is facing up on switch strap.
 - Partially screw in mounting screws in wall box mounting holes.
- NOTE:** Dress wires with a bend as shown in diagram in order to relieve stress when mounting switch.



- Restore power at circuit breaker or fuse.
- Press pad until locator light is OFF. Lights should turn ON.


If lights do not turn ON, refer to the TROUBLESHOOTING section.



Step 6 Switch Mounting: TURN OFF POWER AT CIRCUIT BREAKER OR FUSE.



Installation may now be completed by tightening mounting screws into wall box. Attach wallplate.



Step 7 Restore Power:



Restore power at circuit breaker or fuse. Installation is complete.

OPERATION

NOTE: The locator light will illuminate when the load is in the OFF position to facilitate access in the dark.

Rocker Pad (Default settings)

Turn ON from OFF position:


Tap top of rocker – Lights turn ON.

Turn OFF from ON position:

Tap bottom of rocker – Lights turn OFF.

If there is a power outage, when the power is restored, the lights will return to the last setting before the power interruption.

Cleaning: Clean with a damp cloth. **DO NOT** use chemical cleaners.



SETUP

Leviton Decora Smart™ accessories are compatible with a variety of HomeKit-enabled apps. Leviton recommends using the Leviton Decora Smart Home app to add and configure Leviton HomeKit-enabled accessories and to access advanced features.

- Download the Leviton Decora Smart Home app from the App Store.
- Ensure the Leviton accessory is properly wired and power is applied.
- Upon initial power-up the Locator LED will flash green to show the accessory is ready.
- If the Locator LED is no longer flashing green when you are ready to add the accessory proceed to the WAC Reset procedure.

ADDING AN ACCESSORY

HomeKit™ technology makes adding a HomeKit-enabled accessory to the home network quick and easy.

- When the accessory is ready for enrollment the Locator LED will flash green.
- If the Locator LED is not flashing green, proceed to the WAC Reset section to prepare the accessory for learning.
- Ensure the iPhone or iPad is joined to your wireless network before adding the accessory.
- During the initial installation follow app instructions or press + to add an accessory.

WAC RESET

In situations where a wireless access point or password is changed but the configuration of the dimmer needs to remain, use the following WAC Reset procedure. This procedure can also be used to place the accessory in ready mode with the locator LED flashing green:

- Hold the top of the paddle for 7 seconds.
 - After 7 seconds the Locator LED will blink amber.
- Release the top of the paddle and the switch will reset.
- Once the switch has reset the Locator LED will blink green.

LEVITON DECORA SMART™ FEATURES

Leviton Decora Smart™ products contain unique features which can be configured via the Leviton Decora Smart Home app.

Locator LED Setup:

Leviton Decora Smart™ Switches have a locator LED on the bottom of the paddle. The LED can be used to locate the switch in the dark, indicate the current load status or can be turned OFF at all times.

- Status Mode:** Uses the LED to reflect the current state of the light. If the light is currently ON, the LED is ON, if the light is currently OFF, the LED is OFF.
- Locator Mode (default):** Uses the LED to help find the switch in a dark room. If the light is currently OFF, the LED is ON, if the light is currently ON, the LED is OFF.
- LED OFF:** Places the LED in a permanently OFF state.

LED Level Indicator Timeout

The LED indicators on the side of the switch can be programmed to be ON, OFF, or timeout after a predefined period of time.

- Level Indicators OFF
- Level Indicator Timeout (seconds) (default is 3 seconds)
- Levels Indicators Always ON

FACTORY DEFAULT

In situations where a switch needs to be returned to factory default follow these steps:

- Hold the top of the paddle for a total of 14 seconds.
 - After the first 7 seconds the LED turns amber.
 - Continue to hold the top of the paddle until the Locator LED quickly flashes red/amber.
- Release the top of the paddle and the switch will reset.

TROUBLESHOOTING

- Lights Flickering**
 - Lamp has a bad connection.
 - Wires not secured firmly with wire connectors of switch or terminal screws of remote.
- Light does not turn ON and Locator LED does not turn ON**
 - Circuit breaker or fuse has tripped.
 - Lamp is burned out.
 - Neutral not wired to switch (White wire).
 - Confirm that the switch is being supplied from a 120/277V AC, 60 Hz source ONLY.
- Remote does not operate lights**
 - Ensure that total wire length does not exceed 300 ft.
 - Ensure wiring is correct.

FCC COMPLIANCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving Antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/tv technician for help.

FCC CAUTION

Any changes or modifications not expressly approved by Leviton Manufacturing Co., Inc., could void the user's authority to operate the equipment.

IC COMPLIANCE STATEMENT

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

WEB VERSION

WARNINGS AND CAUTIONS

- **TO AVOID FIRE, SHOCK, OR DEATH; TURN OFF POWER** at circuit breaker or fuse and test that power is off before wiring!
- To be installed and/or used in accordance with electrical codes and regulations.
- If you are unsure about any part of these instructions, consult an electrician.
- The Decora Smart™ DH15S is not compatible with standard 3-way or 4-way switches.
- Use only (1) Decora Smart™ DH15S switch in a multi-location circuit with up to 9 coordinating remote switches (DD0SR-01Z), or up to 4 matching remote switches (DD0SR-DLZ).
- Maximum wire length from switch to all installed remotes cannot exceed 300 ft (90m).

WARNINGS AND CAUTIONS

- **TO AVOID FIRE, PERSONAL INJURY OR PROPERTY DAMAGE, DO NOT** install to control a receptacle.
- Recommended minimum wall box depth is 2-3/4".
- Use this switch **with copper or copper clad wire only**.
- Save this instruction sheet. It contains important technical data along with testing and troubleshooting information which will be useful after installation is complete.
- Leviton HomeKit-enabled accessories rely on Wi-Fi® communication. Increasing the number of Wi-Fi® accessories can affect Wi-Fi® performance. Consult the network's wireless access point specifications to determine the maximum number of supported Wi-Fi® accessories. For installations with a large number of Leviton HomeKit™ Wi-Fi® accessories, a high performance wireless access point capable of supporting a large number of accessories may be required.

INTRODUCTION

Leviton's Decora Smart™ accessories are designed to streamline home control with other HomeKit-enabled accessories. Apple HomeKit™ technology provides an easy, secure way to control HomeKit-enabled accessories using Siri voice control on your iPhone or iPad. After installing your Decora Smart™ Switch, configure it from the Leviton Decora Smart Home app with just a few simple steps.

WARNING: TO AVOID FIRE, PERSONAL INJURY OR DEATH

DO NOT USE the remote for the control of high power heating appliances such as portable heaters. There can be some unexpected consequences if not used with care. For example, an empty coffee pot can be remotely turned on. If that should happen, your coffee pot could be damaged from overheating. If an electric heater is turned on by remote control while clothing is draped over it, a fire could result. This switch will not control lighting that is used with electronic low-voltage and high frequency power supply transformers, nor high pressure discharge lamps (HID lighting). This includes mercury-vapor, sodium vapor and metal halide lamps.

Decora Smart™ accessories are ideal for living rooms, bedrooms, kitchens, dining rooms, home offices, outdoor lighting or anywhere full control of lighting is desired.

RATINGS

Incandescent	-	1800W - 120VAC, 60Hz
LED/CFL	-	5A, 600W - 120VAC, 60Hz
Fluorescent	-	15A - 120VAC, 60Hz
	-	8A - 277VAC, 60Hz
Resistive	-	15A - 120VAC, 60Hz
Motor	-	1/2 HP - 120VAC, 60Hz

FEATURES

- The Decora Smart™ Switch is HomeKit-enabled using Wi-Fi® technology for residential applications
- Compatible with the Leviton Decora Smart Home app as well as other HomeKit-enabled apps
- Over The Air (OTA) firmware updates via the Leviton Decora Smart Home app
- Single pole or three way compatible
- Ease of installation - No new wiring

REQUIRED

- Wi-Fi® Network
- Free Leviton Decora Smart Home app
- Controlling this HomeKit-enabled accessory away from home requires an Apple TV (3rd generation or later) with Apple TV software 7.0 or later and an iPhone or iPad with iOS 8.1 or later


TOOLS NEEDED TO INSTALL YOUR SWITCH

Slotted/Phillips Screwdriver Electrical Tape Pliers
Pencil Cutters Ruler


Changing the color of your Switch:

Your switch comes with two color options. The switch ships with the White frame attached. To change color of frame, proceed as follows:

Push in sides at bottom tabs and pull outward to release



Insert top tabs and press in bottom tabs to attach



INSTALLING YOUR SWITCH


NOTE: Use check boxes when Steps are completed.

Step 1 **WARNING: TO AVOID FIRE SHOCK OR DEATH; TURN OFF POWER** at circuit breaker or fuse and test that power is off before wiring!



Step 2 **Identifying your wiring application (most common):**

NOTE: If the wiring in your wall box does not resemble any of these configurations, consult an electrician.



Single Pole

1. Line (Hot)
2. Neutral
3. Ground
4. Load



3-Way

1. Line or Load (*see important instruction*)
2. Neutral
3. Ground
4. First Traveler – note color
5. Second Traveler – note color


IMPORTANT : For 3-Way applications, note that one of the screw terminals from the old switch being removed will usually be a different color (Black) or labeled Common. Tag that wire with electrical tape and identify as the common (Line or Load) in both the switch wall box and remote wall box.

Step 3 **Preparing and connecting wires:**

This switch can be wired using side wire terminal screws or through backwire openings. Choose appropriate wire stripping specifications accordingly.




Side Wire Connection
Side wire terminals accept #14-12 AWG solid copper wire only.




Back Wire Connection
Back wire openings accept #14-12 AWG solid copper wire only.

- Make sure that the ends of the wires from the wall box are **straight (cut if necessary)**.
- Remove insulation from each wire in the wall box as shown.
- **For Single-Pole Application, go to Step 4a.**
- **For 3-Way Coordinating Remote (no LED) Application, go to Step 4b.**
- **For 3-Way Matching Remote (with LED) Application, go to Step 4c.**

Step 4a **Single Pole Wiring Application:**



Terminal Label:
Use terminal for 3-way or more applications only. For single-pole applications, **DO NOT** remove label.





WIRING SWITCH:

Connect wires per WIRING DIAGRAM as follows:

- Green or bare copper wire in wall box to Green terminal screw.
- Line Hot wall box wire to terminal screw marked "BK".
- Load wall box wire to terminal screw marked "RD".
- Line Neutral wall box wire to terminal screw marked "WH".
- Switch terminal screw marked "YL/RD" should have Red insulating label affixed.
- **NOTE:** If insulating label is not affixed to terminal screw marked "YL/RD", use electrical tape to cover.
- **Proceed to Step 5.**

Step 4b **3-Way Wiring with DD0SR-01Z Coordinating Remote (no LED) Application:**



NOTE: The switch must be installed in a wall box that has a Line Hot and Neutral connection. The coordinating remote must be installed in a wall box with a Load connection and a Neutral connection. A Neutral wire to the coordinating remote needs to be added as shown. If you are unsure about any part of these instructions, consult an electrician.

NOTE: Maximum wire length from switch to all installed remotes cannot exceed 300 ft (90 m).

WIRING SWITCH (wall box with line hot connection):

Connect wires per WIRING DIAGRAM as follows:



- Green or bare copper wire in wall box to Green terminal screw.
- Line Hot (common) wall box wire identified (tagged) when removing old switch to terminal screw marked "BK".
- First Traveler wall box wire to terminal screw marked "RD" (**note wire color**).
- Remove Red insulating label from terminal screw marked "YL/RD".
- Second Traveler wall box wire to terminal screw marked "YL/RD" (**note wire color**). This traveler from the switch must go to the terminal screw on the remote marked "YL/RD".
- Line Neutral wall box wire to terminal screw marked "WH".

WIRING COORDINATING REMOTE (wall box with load connection):

Connect wires per WIRING DIAGRAM as follows:

- "BK" and "RD" terminals on coordinating remote are unused. Tighten both screws.
- Green or bare copper wire in wall box to Green terminal screw.
- Load wall box wire identified (tagged) when removing old switch to First Traveler (**note color as above**).
- Second Traveler wall box wire (**note color as above**) to terminal screw marked "YL/RD". This traveler from the remote must go to the terminal screw on the switch marked "YL/RD".
- Remove White insulating label from terminal screw marked "WH".
- Line Neutral wall box wire to terminal screw marked "WH".
- **Proceed to Step 5.**

Step 4c **3-Way Wiring with DD0SR-DLZ Matching Remote (with LED) Application:**



NOTE: The switch **must** be installed in a wall box that has a Load and Neutral connection. The matching remote must be installed in a wall box with a Line Hot connection and a Neutral connection. A Neutral wire to the matching remote needs to be connected as shown. If you are unsure about any part of these instructions, consult an electrician.

NOTE: Maximum wire length from switch to all installed remotes cannot exceed 300 ft (90 m).

WIRING MATCHING REMOTE (wall box with line hot connection):

Connect wires per WIRING DIAGRAM as follows:

- "RD" terminal on matching remote is unused. Tighten screw.
- Green or bare copper wire in wall box to Green terminal screw.
- Line Hot (common) wall box wire identified (tagged) when removing old switch and First Traveler to Remote terminal marked BK.
- Second Traveler wall box wire from switch to remote terminal screw marked "YL/RD" (**note wire color**). This traveler from the remote must go to Yellow/Red switch terminal screw.
- Line Neutral wall box to remote terminal screw marked "WH".

WIRING SWITCH (wall box with load connection):

Connect wires per WIRING DIAGRAM as follows:

- Green or bare copper wire in wall box to Green terminal screw.
- Load wall box wire identified (tagged) when removing old switch to Red terminal screw.
- First Traveler Line Hot to Black terminal screw.
- Remove Red insulating label from Yellow/Red terminal screw.
- Second Traveler wall box wire (**note color as above**) to Yellow/Red terminal screw. This traveler from the switch must go to the terminal screw on the remote marked "YL/RD".
- Line neutral wall box wire to White terminal screw.
- **Proceed to Step 5.**

WEB VERSION